QUACK START GULDE



Dodge Challenger





Garage Door Opener



- While the car is ON, hold the handheld garage door transmitter 1-3 inches from the HomeLink® button you want to program in the vehicle.
- Push and hold both the HomeLink® button being programmed and the button on the garage door transmitter.

TO ERASE ALL SET CHANNELS:

Push and hold the two outside HomeLink® buttons for 20 seconds until the orange indicator flashes. An individual channel cannot be erased.



ROLLING OR NON-ROLLING?

Check your garage door opener motor in your garage for a "LEARN" or "TRAIN" button by the hanging antenna. If you have one of these, you have a Rolling Code garage door opener.



For Non-Rolling Code garage door openers, watch for the indicator light to go constant.

For Rolling Code garage door openers, watch for the indicator light to go from a slow blink to blinking rapidly.



For Rolling Code garage door openers only, firmly push and release the "LEARN" or "TRAIN" button on your garage door opener motor in your garage, then push the HomeLink® button in your vehicle three times (holding the button for two seconds each time).



If the programming was successful, your garage door should open and close with your chosen HomeLink® button.

Scan For HomeLink® Video





Pair a Phone



Make su your mol

Make sure Bluetooth® is enabled on your mobile device.

With the vehicle in the ACC or ON/RUN position, press the Phone button on the vehicle's touchscreen menu bar.

Press "Pairing".

Press "Paired Phones and Audio Devices".

Select "Add Device" then follow the prompts on your phone and on the touchscreen.

CONNECT YOUR APPS

Connect your smartphone to the media USB port.

The Android Auto™ or Apple CarPlay® icon will replace the phone icon on the touchscreen.

KEEP IN MIND:



For Android™ Users, if the Android Auto™ app was not previously downloaded, it will download the first time you plug in your device.



For Apple® Users, Apple CarPlay® is only compatible with iPhone® 5 or later and requires Siri being enabled in Settings.

Ready to remove a phone or audio device?

- 1 Press the Pairing button on the touchscreen.
- Press "Paired Phones and Audio Devices".
- Press "Settings" next to the phone or device you want to remove.
- Press "Delete Device".
- Press "X" to exit the settings screen. The device should be removed.



Connected Services



WITH CONNECTED SERVICES YOU CAN...



Lock Your Vehicle



Unlock Your Vehicle



Remote Start Your Vehicle



Cancel Remote Start



Activate Your Horn

ACTIVATE YOUR REMOTE SERVICES



- Press "Apps" on the touchscreen.
- 2 Press "Activate Services".
- 3 Press "Activate Now".
- There are two ways to activate: via email or via an agent. On the next page, you can either enter your name and email, or press "Call An Agent" to directly speak with a certified agent.

Mopar® YOUR Way

CREATE YOUR OWNER'S PROFILE TODAY!

Get 24/7 Access To Everything You Need



Custom vehicle dashboard



Access to your vehicle's Owner's Information



Schedule dealer service with ease



Obtain special offers on Mopar® service



View maintenance records**



Mobile vehicle commands*






Registration is simple.
Provide your email address to get started.



*Canadian residents are not required to create a profile, as one is created when a SiriusXM Guardian™ account is activated.

^{**}Requires an active SiriusXM Guardian™ subscription





KEEP IN MIND:

Vehicles sold in Canada are equipped with a headlight switch with an AUTO and ON detent but without an OFF detent. Headlights will be deactivated when the headlight switch is placed in the parking lights position. However, the Daytime Running Lights will be activated along with the front and rear marker lights.

Climate Controls

Rotating the **Blower Control Knob** regulates the amount of air forced through the system in any mode.



Scan For Climate Controls Video

TIP:

Push the **red arrow** button to increase the temperature or push the **blue arrow** button to decrease the temperature for the driver and/or the passenger.

Deluxe Vehicle Security System

The Deluxe Vehicle Security system monitors your doors, hood latch, trunk, and ignition switch for unauthorized entry and operation. It also monitors your vehicle with dual function intrusion sensors and vehicle tilt sensors.

To Arm The System

- 1 Make sure the ignition is OFF.
 - Push the interior power lock switch,
- push the lock button on a Passive Entry door handle, or push the lock button on the key fob.
- 3 Ensure the doors, windows, and sunroof are closed.



To Disarm The System

- Push the unlock button on the key fob or grab the Passive Entry door handle to unlock the door.
- 2 Cycle the vehicle ignition system out of the OFF position.

TIP:

The intrusion sensor can be disabled by pressing the lock button on the key fob three times within 15 seconds of arming the system while the Vehicle Security Light is flashing rapidly.

KEEP IN MIND:

The Deluxe Vehicle Security system will not arm if you lock the doors using the manual door lock.



TIP:

Through the Uconnect touchscreen, you can access Performance Pages or SRT Drive Modes (if equipped). You can access Launch Mode or adjust vehicle performance settings with Sport Mode or Track Mode. Refer to the Performance Features Guide for further information.

Scan For **ParkSense** Video






Turn your ParkSense system on or off by using the ParkSense switch. The chime volume settings can be programmed through your radio.

Scan For **FCW Video**


Scan For **ACC Video**







- Blind Spot Alert Lights Only
- Blind Spot Alert Lights/Chime
- Blind Spot Alert Off



Warning & Indicator Lights

*	Air Bag	= =	Battery Charge	BRAKE	Brake		Door Open		Electric Power Steering (EPS) Fault
) /(Electronic Throttle Control	£	Engine Coolant Temperature	927	Oil Pressure	also	Oil Temperature	A	Seat Belt Reminder
	Transmission Temperature		Trunk Open		Vehicle Security	(ABS)	Anti-Lock Brake System (ABS)	5	Electronic Stability Control (ESC) Active
OFF.	Electronic Stability Control (ESC) OFF	Ç	Engine Check/ Malfunction Indicator	OFF	Forward Collision Warning (FCW) OFF	50	Loose Fuel Filler Cap		Low Fuel
	Low Washer Fluid	2	Service Adaptive Cruise Control (ACC)	SERV AWD	Service All-Wheel Drive (AWD)	≥ <u>‡</u>	Service Forward Collision Warning (FCW)	(!)	Tire Pressure Monitoring System
	Adaptive Cruise Control (ACC) Set Without Target		Adaptive Cruise Control (ACC) Set With Target	(6)	Cruise Control Set		ECO Mode	却	Front Fog
÷DO÷	Parking Lights/ Headlights On	F	Sport Mode	⇔	Turn Signal		Adaptive Cruise Control (ACC) Ready	(5)	Cruise Control Ready
сиѕтом	Custom Mode	Drag	Drag Mode	31	Speed Warning	5port	Sport Mode	Track	Track Mode
VALET	Valet Mode	≣D	High Beam		The second second	253			